

Lecture (03)

Practical Applications on Arduino Uno Board - III

Dr. Ahmed ElShafee


Dr. Ahmed ElShafee, ACU Fall 2015, Practical App. CS II

```
#define LED 11
int i;
void setup()
{
pinMode(LED,OUTPUT);
}

void loop()
{
for(i=0;i<=255;i++)
{
analogWrite(LED,i);
delay(10);
}
}
```


١

DimmerDCLamp



Dr. Ahmed ElShafee, ACU Spring 2013, GP2013

DimmerDCLamp2




Dr. Ahmed ElShafee, ACU Fall 2015, Practical App. CS II

٢


```
#define LED 11
int i;
void setup()
{
pinMode(LED,OUTPUT);
}
void loop()
{
for(i=0;i<=77;i++)
{
analogWrite(LED,i);
delay(10);
}
for(i=77;i>=0;i--)
{
analogWrite(LED,i);
delay(10);
}
}
```

Dr. Ahmed ElShafee, ACU Fall 2015, Practical App. CS II

PressControlledDimmerDCLamp



PotentiometerControlledDimmerDCLamp



```
#define Lamp 11
#define up 7
#define down 4
int up_status;
int down_status;
int i=0;
void setup()
{
pinMode(Lamp,OUTPUT);
pinMode(up,INPUT);
pinMode(down,INPUT);
}
void loop()
{
up_status=digitalRead(up);
down_status=digitalRead(down);
}
```


```
if(up_status==LOW)
{
if(i<128)
i++;
}
else if(down_status==LOW)
{
if(i>0)
i--;
}
analogWrite(Lamp,i);
Delay(10);
}
```

Dr. Ahmed ElShafee, ACU Spring 2013, GP2013

```
#define Lamp 11
#define Potentiometer A0
int pot,Imp;
void setup()
{
  pinMode(Lamp,OUTPUT);
  pinMode(Potentiometer,INPUT);
}
void loop()
{
  pot=analogRead(Potentiometer);
  Imp=int(pot*1.5/4);
  analogWrite(Lamp,Imp);
}
```

Dr. Ahmed ElShafee, ACU Spring 2013, GP2013

LDRControlledDCLamp



Dr. Ahmed ElShafee, ACU Spring 2013, GP2013

```
#define LAMP 11
#define LED 13
#define LDR A0
int pot,Imp;
void setup()
{
  pinMode(LED,OUTPUT);
  pinMode(LAMP,OUTPUT);
  pinMode(LDR,INPUT);
}
void loop()
{
  pot=analogRead(LDR);
  Imp=abs(byte(pot*1.5/4));
  if(Imp>50)
  {
    analogWrite(LAMP,Imp);
    digitalWrite(LED,HIGH);
  }
  else
  {
    analogWrite(LAMP,0);
    digitalWrite(LED,LOW);
  }
}
```

Dr. Ahmed ElShafee, ACU Spring 2013, GP2013

Thanks,

See you next Week, isA